Bedienungsanleitung für Domeyer Geräte- und Flaschenhalter

Allgemeines

Domeyer Geräte- und Flaschenhalter sind vorgesehen, um einsatzfähige Pressluftatmer und deren Reserveflaschen sicher an der Wand eines Geräteraumes zu haltern.

Baugruppen

Gerätehalter für Pressluftatmer mit CFK-Flasche (Durchmesser 156 mm) WT000003

Gerätehalter für Pressluftatmer mit Stahl-Flasche (Durchmesser 140 mm) WT000007

Flaschenhalter für 2 CFK-Flaschen (Durchmesser 156 mm) WT000004

Flaschenhalter für 2 Stahl-Flaschen (Durchmesser 140 mm) WT000008

WT000007

WT000008

Wandmontage

Die Wandmontage der Geräte- und Flaschenhalter ist fachgerecht vorzunehmen. Das Befestigungsmaterial und der Untergrund muss die Last von bis zu 25 kg (je nach Ausführung) statisch und dynamisch aufnehmen können.

Handhabung

Gerätehalter für Pressluftatmer:

Der Pressluftatmer wird mit der Flasche (Position Flaschenventil unten) unten auf die horizontalen gummierten Rohre aufgesetzt und dann mit gleichmäßigem Druck oben in die Klammer gedrückt. Die Flasche muss komplett durch die Klammer aufgenommen sein und unten komplett mit der Flaschenschulter auf den gummierten Rohren aufliegen.

Stand 01/2021

Die Entnahme des Pressluftatmers kann entweder mit einem Ruck am oberen Teil der Bänderung bewerkstelligt werden oder der Pressluftatmer kann vom Geräteträger geschultert werden und dann mit einem leichten Ruck nach vorne aus dem Halter gelöst werden.

Flaschenhalter:

Der Flaschenhalter kann je nach Ausführung 1 oder 2 Flaschen aufnehmen. Die Flasche (n) wird mit dem Flaschenboden nach unten in den Aufnahmering gestellt und anschließend in die Klammer gedrückt. Die Flasche(n) muss komplett durch die Klammer umschlossen sein.

Die Entnahme der Flasche(n) erfolgt in umgekehrter Reihenfolge, d.h. die Flasche(n) wird durch einen leichten Ruck am Flaschenventil aus der Klammer gezogen und anschließend mit beiden Händen aus dem Halter genommen.

Funktionsüberprüfung

Es ist zu empfehlen, regelmäßig den Halter im Ganzen auf Unversehrtheit zu überprüfen und speziell die Spannung der Klammer monatlich durch Entnahme des Pressluftatmers oder der Flasche(n) zu testen.

Achtung! Es dürfen nur Original Ersatzteile (Kunststoffklammer) verwendet werden.

Kontakt: www.domeyer.eu oder info@domeyer.eu

Stand 01/2021

Operating instructions for Domeyer SCBA- and cylinder brackets

General

Domeyer apparatus- and cylinder brackets are designed to store useable SCBA and reserve cylinders securely on the wall of an apparatus room.

Assemblies

Equipment bracket for SCBA with CFRP cylinder (diameter 156 mm) WT000003

Equipment bracket for SCBA with steel cylinder (diameter 140 mm) WT000007

Cylinder bracket for 2 CFRP cylinders (diameter 156 mm) WT000004

Cylinder bracket for 2 steel cylinders (diameter 140 mm) WT000008

WT000007

WT000008

Wall mounting

The wall mounting of the device- and cylinder brackets must be carried out professionally. The mounting material and the substrate must be able to absorb the load of up to 25 kg (depending on the design) statically and dynamically.

Handling

Bracket for compressed air breathing apparatus:

The SCBA is placed with the cylinder (position cylinder valve down) on the bottom of the horizontal rubberized tubes and then pressed into the top of the clamp with even pressure. The cylinder must be completely received by the clamp and rest completely with the cylinder shoulder on the rubberized tubes at the bottom.

Removal of the SCBA can be accomplished by either jerking the top of the shoulder straps or the SCBA can be shouldered by the wearer and then released from the bracket with a slight forward jerk.

Bracket for compressed air cylinders:

The cylinder bracket can accommodate 1 or 2 cylinders depending on the design. The cylinder(s) is (are) placed in the ground ring with the bottom of the cylinder facing downwards and then pressed into the clamp. The cylinder(s) must be completely enclosed by the clamp.

The cylinder(s) is (are) removed in reverse order, i.e. the cylinder(s) is (are) pulled out of the clamp by a slight jerk on the cylinder valve and then removed from the bracket with both hands.

Functional check

It is recommended to regularly check the bracket as a whole for integrity and especially to test the tension of the clamp monthly by removing the compressed air breathing apparatus or the cylinder(s).

Attention. Only original spare parts (plastic clamp) may be used.

Contact: www.domeyer.eu or info@domeyer.eu

Stand 01/2021